SHIP SAMPLES TO:

SCN Diagnostics

1054 East Campus Loop University of Missouri Columbia, MO 65211-5315

Ph: (573) 884-9118

Email: scndiagnostics@missouri.edu

1st Sample is free per grower! Extra samples will be charged

\$25 per sample

(PPDL-3-W) SCN Survey

Office Use Only:				
•				
Date received:				
Date received:				
Cample #				
Sample #:				
A				
Account #: <u>Darcy Telenko</u>				
·				

Sponsored by the SCN Coalition and the Telenko Lab



SOYBEAN CYST NEMATODE SURVEY **INDIANA SAMPLES ONLY**

COUNTY OF ORIGIN:		FIELD ID	FIELD ID:			
ıbmitter's Naı	me		Client's Name			
usiness			Business	Business		
ldress			Address			
			-			
-	County			County		
	Fax			Fax		
nail			Email			
nformation ab	oout Submitter/Client (ple	ase check o	ne each for submitter & cli	ient)		
Submitter Client		Submitte	r Client	Mail reply to: SubmitterClien		
	Extension Educator		Consultant	Fax reply to: SubmitterClien		
	Farmer		Purdue Specialist	Email reply to: SubmitterClien		
	Dealer/Industry Rep		Other	Copy Extension Educator		
	Pattern Scattered Small areas Large areas Low spots		Degree of damage (choose one) Heavy Medium Light	Soil type sandy clay silt loam organic		
revious Crop:		Variety:				
ample Number:		Notes:				
		_				
		-				
		-				
		_				
		_				

How to take soil samples for SCN Testing

The equipment you need for sampling soil for soybean cyst nematode is the same equipment you use for taking a soil sample for soil nutrient analysis: a soil probe, a bucket, and a plastic soil bag.

To collect soil samples for SCN diagnosis, we recommend you collect 10 to 20 of cores of soil, each with 1 inch-diameter and 6 to 8 inches-depth in a 20-acre area. If the field is larger, break the field into 20-acre units and take 10 to 20 cores per unit.

Take cores from within root zones and use a zig-zag or M-pattern to collect soil cores. In addition, you may also want to include samples from a high-risk area, such as near a field entrance, areas where the yield seems to be a little lower than the last time soybeans were grown, or along fence lines where wind-blown soil accumulates.

Bulk the cores in a container and mix thoroughly. Take the time to mix the sample. The better the sample is mixed the better it represents the whole field. Put $\sim 500~\text{cm}^3$ or 1 pint of the thoroughly mixed soil in a plastic bag and label it with a permanent marker. Don't put a paper label inside the bag. The moist soil will make it unreadable by the time the sample reaches us.

Please keep the sample at room temperature or cooler and keep out of the sun or hot truck cab until you are ready to pack and ship it. Pack the samples in a box and cushion the samples with packing material so the bags don't break open during shipping. Please fill out the attached form, including your name, address, phone number and email address and send with your sample. Be sure to indicate the county where the sample was collected and any field designation needed to help you identify the location when your results are sent. The collection form can also be downloaded from this website: https://ag.purdue.edu/btny/ppdl/Pages/physicalspecimens.aspx

